

520 SERIES

REPAIR PARTS INDEX

PUMP SIZE	PAGE
1"	3
1¼"	
1½"	
2"	

PIECE NO.

- 12 - ONE SUPPORT PIPE USED UP TO 5'-1" PIT
TWO SUPPORT PIPES USED 5'-2" TO 9'-0" PIT
THREE SUPPORT PIPES USED 9'-1" TO 10'-6" PIT
- 22 - A ROD GUIDE IS REQUIRED WITH ALL REPLACEMENT
COVERS. PC NO. 22A.
- 41 - ONE GUIDE BEARING REQUIRED 5'-2" TO 9'-0" PIT
TWO GUIDE BEARINGS REQUIRED 9'-1" TO 10'-6" PIT

520 SERIES

MODEL 521A-522A

PIECE NUMBERS



